



Magic Gadgets

2K CONNECTOR MODIFICATION INSTRUCTIONS

THIS MODIFICATION CAN USUALLY BE DONE WITHOUT REMOVING THE CONNECTOR.



UNITS WITH SHORT (OR CUT OFF) TABS

STEP 1. IF TAB IS BENT OUT OF PLACE, BEND IT BACK WITH A THE FLAT SIDE OF A SCREWDRIVER BLADE. ENSURE THAT IT IS BENT AS CLOSE AS POSSIBLE TO THE INSULATING SURROUND

STEP 2. CLEAN THE METAL AND THE SURROUNDING AREA IF NECESSARY.

STEP 3. APPLY A BLOB OF "GOOP" BRAND ADHESIVE TO EACH TAB BEGINNING WITH THE INSIDE OF THE METAL PART AND DRAGGING THE BLOB OUT OVER THE SIDE OF THE INSULATING SURROUND. BE CAREFUL NOT TO ALLOW THE "GOOP" TO RUN INTO THE CONNECTOR SPRING CONTACT AREA AS IT WILL BLOCK CONNECTOR ENTRY WHEN IT DRIES.

STEP 4. STAND THE UNIT ON END, WITH THE GOOPED AREA UP, SO THAT THE ADHESIVE WILL SETTLE AROUND THE METAL PARTS. WAIT 24 HOURS.



UNITS WITH LONG (OR BENT FLAT) TABS

STEP 1. IF TAB IS BENT OUT OF PLACE, BEND IT BACK WITH A THE FLAT SIDE OF A SCREWDRIVER BLADE THEN, IF NECESSARY, BEND EACH TAB FLAT AGAINST THE INSULATING SURROUND.

STEP 2. CLEAN THE METAL AND THE SURROUNDING AREA IF NECESSARY.

STEP 3. APPLY A BLOB OF "GOOP" BRAND ADHESIVE TO EACH TAB BEGINNING WITH THE ENTIRE TOP OF THE METAL PART AND DRAGGING THE BLOB OUT OVER THE SIDE OF THE CONNECTORS INSULATING SURROUND. BE CAREFUL NOT TO ALLOW THE "GOOP" TO RUN INTO THE CONNECTOR SPRING CONTACT AREA OR IT WILL BLOCK CONNECTOR ENTRY WHEN IT DRIES.

STEP 4. STAND THE UNIT ON END, WITH THE GOOPED AREA UP, SO THAT THE ADHESIVE WILL SETTLE AROUND THE METAL PARTS. WAIT 24 HOURS.

! IMPORTANT !

NOTE 1. "GOOP" BRAND ADHESIVE IS THE ONLY MATERIAL WE HAVE FOUND THAT HAS THE STRENGTH AND ADHESION FOR NECESSARY. DO NOT USE ANY OTHER MATERIAL AS THE RESULTS WILL NOT BE SATISFACTORY. **ALLOW THE "GOOP" TO CURE FOR AT LEAST 24 HOURS BEFORE USING OR REATTACHING THE CONNECTOR.**