



# Magic Gadgets

## SHADOWMAKER GUARD INSTALLATION (OLDER UNITS)

NEW UNITS HAVE PRE-THREADED HOLES



STEP 1. POSITION THE GUARD OVER THE CONNECTORS WITH THE TWO MOUNTING HOLES EQUALLY SPACED LEFT TO RIGHT. MARK BOTH HOLES WITH A PENCIL.



STEP 2. PUNCH THE CENTER OF BOTH OF THE MARKS MADE IN STEP 1.



STEP 3. WITH A 9/64" BIT, DRILL THE TWO HOLES *VERY SLOWLY*. GO ALL THE WAY THROUGH THE METAL (ABOUT 3/32"). BE CAREFUL NOT TO DRILL TOO DEEPLY AS YOU COULD DAMAGE COMPONENTS INSIDE THE UNIT.



STEP 4. ATTACH THE GUARD WITH THE TWO SELF TAPPING SCREWS PROVIDED, THEN UNSCREW THE BOTTOM COVER PLATE AND REMOVE ANY LOOSE METAL PARTICLES. REPLACE THE COVER. DONE!



THE FINISHED INSTALLATION.